



# GUSSET

## PEDAL INSTRUCTIONS

### TOOLS REQUIRED |

**6mm hex key or 15mm pedal spanner** –  
model dependant as listed below

**Prosecutor** – 15mm pedal spanner

**Slim Jim** – 6mm hex key or 15mm pedal spanner

**Merge** – 6mm hex key

**S2** – 6mm hex key or 15mm pedal spanner



\* Image for  
instructional  
purposes only

*Note: All of our pedals are 9/16th thread pitches with left and right hand specific axles, this is in orientated as if you were sat on the bike. Each pedal has an 'L' or 'R' marking on the flat spot or end of the axle to denote which is which. If you are unsure, please consult your favoured qualified bicycle mechanic.*

#### Installation:

- 1) Ensure crank threads are clean and undamaged.
- 2) Taking the left hand pedal, apply some high quality grease to the threads and locate pedal in left hand crank making sure that the pedal is perpendicular to the crank and the threads aligned to prevent cross threading.

*Note: The left hand pedal and crank are left hand thread, so tighten anti-clockwise to 41Nm.*

3) Once the left hand pedal is tightened to torque repeat step 2 for the right hand pedal, noting that the threads are right hand, tighten clockwise to 41Nm.

4) Go ride your bike

#### Maintenance of your pedals:

Before each ride, check your pedals are tight in the crank arm and do not show signs of play on the axles. Should you have any doubts, please consult your favoured qualified bicycle mechanic.

Our loose ball pedals (Prosecutor and Slim Jim LB) will need oiling periodically. To do this lay the bike over and drip in some thick oil between the axle and pedal body, circulating through the bearings by turning the pedal body.

Designed in the U.K

g u s s e t c o m p o n e n t s . c o m



Recycle this packaging | Made in Taiwan